

Installation Guide

Attaching Skirt Assembly to:

- RHIUTH Top Hat Housing, or
- RHIU2X2 Tile Ceiling Mount

This guide explains how to attach the skirt assembly to the top hat housing or 2x2 tile ceiling mount used for the SpeedDome Ultra camera dome.

Install Kit Supplied

Install Kit 0100-2294-01, which includes:

Skirt assembly, top hat 1 0400-1145-01

Procedure

Referring to the figure:

1. Take T-lanyard of skirt and bend one end of "T" as shown.
2. Insert T-lanyard into the slot in top hat housing until both ends of "T" extend and catch securely.



WARNING!

Insert T-lanyard exactly as shown to ensure the skirt is securely attached. Ensure that the "T" extends once inserted.

3. Attach skirt to bottom of top hat housing. It is magnetically held in place.

