

REPLACEMENT PARTS LIST

Important Notice

- Components identified by "△" mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.
- RTL : Retention Time Limited.

| REF.NO. | PART NO. | DESCRIPTION | REF.NO. | PART NO. | DESCRIPTION |
|----------------------|--------------|----------------------------------------------------------|---------|----------------|---------------------------------|
| MISCELLANEOUS | | | M27 | YWV9AA2073A4 | Mechanical Assy |
| | | | M28 | YWV9AA2070B4 | Framw for Fan |
| | | | M29 | YWV2HA2028B4 | Shield Parts |
| | | | M32 | YWV2GA1006A4 | Pan Gear |
| | | | M33 | YWM1748A | TR Holder |
| PB1 | YWVCST60KY2A | Sensor Board Assy for WV-CST604 | M37 | YWV5KA2049B1 | Diecast Case |
| MO1,2 | YWVKYCP61P1A | Sensor Board Assy for WV-CS604A | M38 | YWV6FA1007A4 | Bracket |
| MO3 | YWL826002A | DC Motor | M39 | YWV5YA0502AN | Band |
| FB1 | YWF412R12MA1 | DC Motor | M40 | △ YWV2GA1009A4 | Cord Clamp |
| | YWVCS600KC3A | Flexible Board Assy for Drive Board CN7and A/F Board CN2 | M41 | YWV7CA0502A3 | Sealing Packing |
| FB2 | YWVCS600KY3A | Flexible Board Assy for Drive Board CN1 and Sensor Board | M42 | YWV9AA2072A4 | Mechanical Assy |
| FB3 | YWVCS600KY2A | Curl Flexible Board Assy | M44 | YWMN3V0 | Cord Clamp |
| CN1 | YWAXN720535P | 20-pin Connector | M45 | YWV1KA1010A4 | Washer |
| CN2 | YWAXN820535P | 20-pin Connector | M46 | YWV3FA1009A4 | Ring |
| CN3 | YWAXN416430P | 20-pin Connector | M47 | YWV7SA3501A4 | Model Label for WV-CST604 |
| CN4 | AXN420330P | 20-pin Connector | | | |
| CN5 | AXN420330P | 20-pin Connector | | | |
| CN6 | YWAXN320038P | 20-pin Connector | M51 | △ YWV7SA3518A4 | Model Label for WV-CS604A |
| CN101 | △ YWVAR2 | Power Connector | | | |
| E101 | △ YWVCS60P05 | AC Power Cord Assy | M52 | YWV7QA4576A4 | Main Label for WV-CST604 |
| M1 | YWV5EA2034A3 | Lens Cover | | | |
| M4 | YWV2WA1023A2 | Frame for WV-CST604 | M53 | YWV7QA4460A4 | Main Label for WV-CS604A |
| | YWV2WA1012A2 | Frame for WV-CS604A | | | |
| M5 | YWV5EA2217A4 | Blank Cover for WV-CST604 | | | |
| | | | | | |
| | YWV5EA2087A4 | Blank Cover for WV-CS604A | M54 | YWV7QA2372A4 | System Label |
| M6 | YVV0MA1044AN | Tilt Magnet Holder H Assy | M56 | YFV7MB0103A4 | Chock Label |
| M7 | YVV0MA1045AN | Tilt Magnet Holder V Assy | M57 | YWV7MA0374A4 | Connection Caution Label |
| M8 | YWV4EA0513A3 | Gear | M81 | YWV0EA1154AN | Lens Assy for WV-CST604 |
| M9 | YWV7DA1015A4 | Heat Sink | | YWCC301B | Lens Assy for WV-CS604A |
| M10 | YWV9AA2074A4 | Main Frame Assy | M82 | YWVCST60PA2A | Head Optical Assy for WV-CST604 |
| M11 | YWV4JA1033A3 | Spring | | YWVCS600JA2A | Head Optical Assy for WV-CS604A |
| M12 | YWV9AA2300A4 | Camera Shaft Assy for WV-CST604 | M83 | YWV5EA2222A4 | AF Board Cover for WV-CST604 |
| | YWV9AA2109A4 | Camera Shaft Assy for WV-CS604A | M84 | YWV2TA1029A3 | CCD Holder |
| M13 | YVV0MA1047AN | Mechanical Assy | M85 | YWV2TA1030A3 | Mounting Bracket |
| M14 | YWV4JA1028A4 | Spring | | | |
| M15 | YWV4JA1032A4 | Spring | | | |
| M16 | YWV2GA1005A3 | Cord Clamp | M86 | YWV2JA1023A4 | Stud for WV-CST604 |
| M17 | YVV0MA1048AN | Mechanical Assy | M87 | YWV4JA1064A4 | Wave Washer |
| M18 | YWV5EA2030A3 | Dome | M88 | YWV3FA1034A4 | Control Ring |
| M19 | YWV5EA2218A2 | Inner Dome for WV-CST604 | | | |
| | YWV5EA2033A2 | Inner Dome for WV-CS604A | | | |
| M20 | YWV9AA2076C3 | Mechanical Assy | | | |
| M21 | YWV4EA0511A3 | Gear | | | |
| M22 | YWVCS600JA4A | Slip Ring Assy | | | |
| M23 | YWV4JA1036A4 | Spring | | | |
| M24 | YWV5KA2122A2 | Base Plate for WV-CST604 | | | |
| | YWV5KA2050B2 | Base Plate for WV-CS604A | | | |
| M25 | YWV7DA1014A4 | Heat Sink | | | |
| M26 | YVV0MA1046AN | Pan Magnet Holder Assy | | | |